Contents

1. Introdution	3
2. Important Safeguard	4
3. Overview	5
4. Wiring And Installation	7
5. Package	8
6. Specification	9

. Introdution

Your unit is designed so it can be flush mounted on the or used. When flush mounted on the wall, the stand permils you to the unit for an gular of unit view. The model number is located on the bottom and record the serial number in the space provided below(available). Refer to these numbers whenever you call upon your COMMAX dealer regarding this product.

Model No.

Serial No.

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

This symbol is intended to alert the use to the presence of uninsulated "dangerous Voltage" within the product's enclose that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the use to the presence of important operating and maintemance(servicing) instructions in the literature accompanying the appliance



caution

Rosk of electric shock do not open




CAUTION: To reduce the risk of electrix shick, do not remove cover(or back) no user-serviceable part sinside refer servicing to guarred service personnel

2. Important Safeguard

- ▲ Damage Requiring Service: This equipment from the power source and source and refer servicing to qualified service personnel under the following conditions:
 - (a) when the power is damaged.
 - (b) if liquid has been spiled or objects have hallen into the unit
 - @ if the equipment has been exposed to rain or water.
 - a) if the equipment has beem dropped or otherwise damaged.
 - when the equipment exhibits a distinct change in performance- this indicates a need for service.
- ▲ Water and Moisture: Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundru tub, in a wet basement, or near a swimming pool, and the like.
- Accessories: The product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Any mounting of the manufacture's insturctions, and should use a mounting accessory recommended by the manufacturer.
- ▲ Object and Liquid Entry: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product
- ▲ Lightning: For added protection for this product before a lihatning storm, or when it is left un attached and un used for long periods of time, unplug it from the wall outlt and disconnect the other system. This will prevent damage to the product due to lightming and power-line surges. If you live in an ared heavily prone to lightning stoms, it is recommended that you invest in powerline, telephone-line, RFcable and actuator/ polarization surge protectors to protect your appliance system from possiple damage


3. Overview




No.	Name	Details				
1	Front panel					
2	LED	Since it acts as lighting at night, it provides better picture quality.				
3	Camera lens	It delivers images. (Make sure to keep it clean to prevent dust)				
4	Microphone	It delivers voices at a time of communication with residences.				
5	Call button	It is pressed to call a residence.				
6	Speaker	It delivers voice from a residence.				
7	NAME CARD					
8	Angle adjustment lever	Use it to adjust the angle of the view of visitors according to installation environment.				
9	Monitor & Door release	It connects monitor (careful about polarity) to a door release.				
	connection terminal					
10	Screw hole					
11	Backside panel					
12	Camera bracket					

4. Wiring And Installation

- 1. Fix it by adjusting the hole in the installation wall and bracket hole.(SCREW T4×18)[FIG-1]
- 2. Wire the residence monitor cables as shown in the figure.[FIG-2](#1:VOICE, #2:GND, #3:DC12V, #4:VIDEO)
- 3. Wire the door release as shown in the figure.[FIG-2](#5,#6)
- 4. Fix it by using screw (M4×8) and then put on the rubber-cap.[FIG-1]
- 5. Put on the name card cover.[FIG-1]



5. Package



7

8

6. Specification

Model No.	DRC-4BH			DRC-4CH		
Rated voltage/Current consumption	DC 12V (Supplied t	to monitor)		DC 12V (Supplied to monitor)		
Wiring(Main Unit/Switch)	4-wire system (polar) / 2-wire			4-wire system (polar) / 2-wire		
	system (non-polar)			system (non-polar)		
CCD	1/3" (Solid CCD)			C.C.D (Solid state imaging device)		
Communication	Simultaneous communication			Voice switching		
Burton	EIA(15.734KHz/60)	Hz)		NITOO OL I		
Broadcasting	/CCIR(15.625KHz/50Hz)			NTSC Standard		
Horizontal/vertical	0 Lux(Up to 300mn	n from the front		0.1 Lux (Up to 300mm from the front		
scan frequency	of the camera)			of the camera)		
Lighting	Infrared LED built-i	n		built-in white LED (operated at a night time)		
Camera angle	Horizontal 68°, vertical 55°			Horizontal 75°, vertical 55°		
Angle adjustment	Upward 13°, downward 13°			Upward 13°, downward 13°		
Operation temperature	-10°C ~ + 50°C			-10°C ~ + 50°C		
Weight (g)	680g			680g		
Dimensions (mm)	116(W) x 169(H) x 42.5(D)			116(W) x 169(H) x 42.5(D)		
Transmission	Dianeter(pie)	0.5		0.65	0.8	1
distance (TIV Cable)	group(M)	28		50	70	115

Memo

10








DOOR STATION

Model No. DRC-4BH/4CH



COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept.: Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site: www.commax.com

Printed In Korea/ 2007.07

COMMAX Co.,Ltd.

- · Thank you for purchasing our COMMAX product.
- Please carefully read this User's Guide (in particular, precautions for safety)
 before using the product and follow the instructions to use your productexactly.
- The company is not responsible for any safety accidents caused in abnormal operation of the product.